

TRUE-TRACK, INC.™

TRUE TRACK TOURING FRONT LOWER STABILIZER

P/N #20-00-09FT

- 1) LOOSEN FRONT MOTOR MOUNT BRACKET BOLTS AND DISCARD THE TWO NUTS AND FLAT WASHER ON ENGINE CASE.
(MOST BIKES HAVE THE BOLTS INSERTED FROM THE BOTTOM UP, IF INSERTED FROM THE TOP DOWN THEY HAVE TO BE REMOVED AND INSTALLED FROM THE BOTTOM UP)
CLEAN SURFACES OFF, LAY ENGINE BRACKET ACROSS ENGINE CASE AND CATCH ONE BOLT AT A TIME AND TIGHTEN BOLTS TO 30 FT LBS. USE **BLUE LOCTITE** ON BOLTS.
- 2) REMOVE UPPER AND LOWER FORWARD BOLTS ON KICKSTAND BRACKET. YOU WILL HAVE TO SUPPORT BIKE WITH A FLOOR JACK OR YOUR MOTORCYCLE JACK. YOU CAN USE THE FRAME BRACKET TO LOCATE PROPER HOLES. USING NEW BOLTS PROVIDED, INSTALL THE FRAME BRACKET AND TIGHTEN TO 30FT LBS. USE **BLUE LOCTITE** ON THESE BOLTS ALSO.
- 3) LASTLY, ADJUST HEIM JOINT TO A NEUTRAL POSITION AND LOCK JAM NUTS AND YOU'RE READY.



PART LIST:

- 1] HEIM JOINT ASSY
- 2] 2 3/8X16- 1 1/2 LONG ROUND HEAD ALLEN
- 3] 2 3/8X16- 2 LONG ROUND HEAH ALLEN
- 4] 4 3/8 FLAT WASHERS
- 5] 1 ENGINE BRACKET PART # 20-00-09 FT1
- 6] 1 FRAME BRACKET PART # 20-00-09 FT2

QUESTIONS? CALL TECH AT 818-445-6204